

# **Avaya B169 Conference Phone**

The Avaya B169 is a battery powered, wireless conference phone that can be connected to the DECT base station included in the package, to a mobile phone, or to a PC.



SD memory card port

It is possible to record a call in progress and use the Avaya B169 as a dictaphone.

Press the • L button to start and stop recording. Recordings can be accessed via the menu.

Flashing blue Steady blue light Incoming call


Call in progress Flashing red

Hold, microphone and speaker turned

off

Steady red light Mute, microphone turned off

#### Display symbols




# Charging the battery

Charge the battery by placing the Avaya B169 on the charging stand or plug the power cable into the Avaya B169.

A fully-charged battery provides up to 60 hours of talk time. The Avava B169 lets you know when there is less than one hour of talk time left



# **DESCRIPTION**



### **NAVIGATE IN MENUS AND MAKE SETTINGS**

The Avaya B169 menu contains the following options:

CALL LIST PHONE BOOK CONF GUIDE RECORDING SETTINGS STATUS


- ⇒ Press ※.
- ⇒ Select the option you want from the menu using the arrow keys. Press **OK** to confirm.
- ⇒ Cancel the setting or go back one level in the menu by pressing
- ⇒ Quit the menu by pressing ★ again.
- Note that after you have made changes to a setting, you must press OK to activate the setting.

# **GETTING STARTED**

#### BASE STATION REGISTRATION

- ⇒ Put the base station in registration mode.
- ⇒ Select ★ > SETTINGS > DECT > REGISTER.
- $\Rightarrow$  Select a base (1-4).
- ⇒ Enter the base station's PIN code.
- ① The default code is **0000** for the *Avaya DECT* base station.

The conference telephone will now search for a base station. The base station has to be in registration mode. If registration was successful, the word SUCCESS will appear in the display.



#### **USING A COMPUTER**

- ⇒ Connect the Avaya B169 to a computer using the USB cable provided.
- □ Check that Avaya B169 is set as the sound device in the computer's settings.

# Making VoIP calls

Make the call (or answer an incoming call) using the computer's VoIP software, for example a web conference software, OneX® Communicator or Scopia®.

## **USING A MOBILE PHONE**

- ⇔ Connect a mobile phone using an accessory cable.
- ⇒ Press the key. Select **MOBILE** and press **OK** to confirm.

# Making mobile calls

- ⇒ Press **J** to activate the Avaya B169.
- ⇒ Connect the call with the mobile phone.

# **MULTI-PARTY CALLS**

# ANSWERING AND MAKING CALLS

- ⇒ Press **J** to answer an incoming call.
- ⇒ Dial the number and press J to make a call.
- ⇒ Press an arrow key to open a call list containing previously dialled numbers. Call using **J**.
- Press and hold an alphanumeric button for two seconds to call a contact in the phonebook.

#### **DURING A CALL**

- Adjust the speaker volume using the keys ◄)) and ◄).
- ⇒ Press 🖔 to turn off the microphone.
- ⇒ Press to put the call on hold.

  Both the microphone and the speaker are turned off and the call is on hold.
- ⇒ Press the same button again to reconnect the call.

(i) Note that different PBXs may require different signals. If you experience problems making multi-party calls: Please refer to the manual for information about how to make necessary settings and to your telephone administrator or service provider for specific settings.

#### ADDING A PARTY TO A CALL

- ⇒ Press the J button during the call.

  Calls in progress are put on hold and a second dialling tone is heard.
- ⇒ Dial the second participant's number, press and wait for an answer.
- ⇒ Press the **\*** button to connect all the meeting participants.

## THE CONFERENCE GUIDE

You can create groups of up to six people via 
★ > CONF. GUIDE > ADD GROUP.

- ⇒ Press the 🎎 button and choose a conference group. Press **OK** if you want to see who is in the group and 🥒 to make the call.
- ⇒ Follow the instructions in the guide and answer with **OK** or ...

Calls in progress are put on hold when the next participant calls.

When all participants have been called, they are automatically connected for a conference call.